



## Rechargeable Batteries

For Digital Cameras and Camcorders

Li-Ion: Lithium Ion  
NiMH: Nickel Metal Hydride

Battery	Capacity	Fits These Cameras
BP-511	1400mAh (Li-Ion)	Canon: EOS 10D, 20D (BG-32), D30, D60, & Digital Rebel (300D, Kiss Digital); PowerShot Pro 1, 90, 90is, G1, G2, G3, G5, G6; Canon Camcorder: OPTURA Xi, Pi, 100MC, 200MC, 20, 10; ZR 10; ZR 90/85/80; ZR 20/25MC/30MC; ZR40/45MC/50MC; ZR 60/65MC/70MC
BP-522	2200mAh (Li-Ion)	Canon Camcorder: OPTURA Xi, Pi, 100MC, 200MC, 20, 10; ZR 10; ZR 90/85/80; ZR 20/25MC/30MC; ZR40/45MC/50MC; ZR 60/65MC/70MC
NB-1LH	950mAh (Li-Ion)	Canon: PowerShot S100, S110, S200, S230, S300, S330, S400, S410, S500
NB-2L	720mAh (Li-Ion)	Canon: PowerShot S30, S40, S45, S50, S60; S70 Canon Camcorder: Elura 40mc, Elura 50, Elura 60/65/70; Optura 30, 40, 400, 500
BP-2L12	1200 mAh (Li-Ion)	Canon Camcorder: Elura 40mc, Elura 50, Elura 60/65/70; Optura 30, 40, 400, 500
NB-3L	800mAh (Li-Ion)	Canon: SD 10 (Digital IXUS i), SD 20 (Digital IXUS i5), SD 100 (Digital IXUS II), SD 110 (Digital IXUS IIs)
NB-4L	600mAh (Li-Ion)	Canon: Powershot SD200 [ixus 30], SD300 [ixus 40]
NB-5H	800mAh (NiMH)	Canon: Powershot S10, S20, A50, A5, A5 Zoom
NPE3 (Box)	1800mAh (NiMH)	Canon: EOS 1D, 1Ds, 1D Mark II, 1Ds Mark II
BP-406	650 mAh (Li-Ion)	Canon Camcorder: Optura 300; Elura 2/2 MC, Elura 10, 20mc
BP-412	1200mAh (Li-Ion)	Canon Camcorder: Optura 300; Elura 2/2 MC, Elura 10, 20mc
BP-915	1500mAh (Li-Ion)	Canon Camcorder: VL-10Li Video Light; Vistura; Ultra; ES4000, ES8400V, ES8600, ES75, ES8200V, ES8100V, ES50, ES55, ES8000V, ES7000V, ES6500V, ES420V, ES410V, ES60, ES65, ES300V; XL1; XL1S; GL1, GL2
BP-930	3000mAh (Li-Ion)	Canon Camcorder: VL-10Li Video Light; Vistura; Ultra; ES4000, ES8400V, ES8600, ES75, ES8200V, ES8100V, ES50, ES55, ES8000V, ES7000V, ES6500V, ES420V, ES410V, ES60, ES65, ES300V; XL1; XL1S; GL1, GL2, XL2
NP-20	630mAh (Li-Ion)	Casio: EX-Z4U, EX-Z3, EX-S3, EX-S2, EX-M2, EX-S20U, EX-M20U, EX-S100
NP-40 (Casio)	1230mAh (Li-Ion)	Casio: EX-Z30, EX-Z40, EX-Z50, EX-Z55, EXP600, EXP700
NP-30	565mAh (Li-Ion)	Fuji: F440, F450
NP-60/ D-Li2	1050mAh (Li-Ion)	Casio (NP-30): QV-R3, QV-R4; Fuji (NP-60): Finepix 50i, Zoom 601, 401, 410; Kodak (Klic 5000): DX 7440, DX7630, LS753, LS743, LS633, LS443, LS420; Panasonic (CGA-S301): SV-A10, SV-AV30; Olympus (Li-20B): AZ-1; Pentax (D-L12): Optio 330, 430; Ricoh (DB-40): RR10; Toshiba (PDR-BT3): PDR-T20, T30
NP-40/ D-Li8	750mAh (Li-Ion)	Fuji (NP-40): Finepix F700, F402, F810, E550 Pentax (D-L18): Optio S4, S4i, S, SV
NP-80	1200mAh (Li-Ion)	Fuji (NP-80): Finepix 4900 Zoom, 6800 Zoom, 6900 Zoom, MX-1700, MX-2700, MX-2900. Kodak (Klic 3000): DC 4800, Leica: Digilux Zoom, Ricoh (DB-20): RR1, RDC7, RDC-6000, RDC-4500, Toshiba (PDR-BT1): PDR-M4, PDR-M5, PDR-M70.
NP-100	1800mAh (Li-Ion)	Fuji (NP-100): DS260, MX-600, MX-700, JVC (BN-V101): GC-S5, GC-QX3HD, GC-QX5HD, Leica: Digilux, Ricoh: RDC-4700, Toshiba: PDR-M3
NP-120/ D-Li7	1500mAh (Li-Ion)	Fuji (NP-120): FinePix M603, FinePix F410 Zoom Panasonic: SVAV10, SVSV10a Pentax (DL17): Optio 450, Optio 550, Optio 555, Optio 750Z, Optio MX Ricoh (DB43): G3, G3M, G3S, RR30
BN-V408	800mAh (Li-Ion)	JVC Camcorder: GR-DVL100U, 105U, 107U, 120U, 200U, 210U, 220U, 300U, 307U, 310U, 315U, 317U, 320U, 400U, 500U, 505U, 510U, 517U, 520U, 522U, 600U, 707U, 725U, 800U, 805U, 815U, 820U, 822U, 915U, 920U; DV3000U, 4000US, 500US, 800US; D200US, 30US, 31US, 70US, 90US, 91US
BN-V416	1600mAh (Li-Ion)	JVC Camcorder: GR-DVL100U, 105U, 107U, 120U, 200U, 210U, 220U, 300U, 307U, 310U, 315U, 317U, 320U, 400U, 500U, 505U, 510U, 517U, 520U, 522U, 600U, 707U, 725U, 800U, 805U, 815U, 820U, 822U, 915U, 920U; DV3000U, 4000US, 500US, 800US; D200US, 30US, 31US, 33US, 70US, 90US, 91US; GR-HD1US *HD Camcorder*
KLIC-5001	1750mAh (Li-Ion)	Kodak: Easyshare DX6490, DX7630, DX7440, DX7590
DR-LB4/ NP-500/NP-600	900mAh (Li-Ion)	Konica / Minolta: Digital Revio KD-500Z, 410Z, 400Z, 310Z; Dimage G400, G500, G600
NP-200	750mAh (Li-Ion)	Konica / Minolta: DiMage X, Xi, Xt, Xg
NP-400	1500mAh (Li-Ion)	Konica / Minolta: DiMage A1, A2; Maxxum 7D
NP-700	700mAh (Li-Ion)	Konica / Minolta: Dimage X50
NP-800	800 mAh (Li-Ion)	Konica / Minolta: Dimage A200



# Rechargeable Batteries

For Digital Cameras and Camcorders

Li-Ion: Lithium Ion  
NiMH: Nickel Metal Hydride

Battery	Capacity	Fits These Cameras
BP-780s	780mAh (Li-Ion)	Kyocera: Finecam SL300R, Contax: SL300PT
BP-800s	800mAh (Li-Ion)	Kyocera: Finecam S54, S3, S3X, S4, S5 Konica: KD300Z Toshiba: PDR 3310
BP-DC1	1300mAh (Li-Ion)	Leica: Digilux 1,2 Panasonic: LUMIX DMC-LC5-K, DMC-LC5-S, DMC-LC40, DMC-LC1
BP-DC2	680mAh (Li-Ion)	Leica: D-Lux Panasonic: DMC-F1
EN-EL1	700mAh (Li-Ion)	Nikon: Coolpix 775, 880, 885, 995, 4300, 4500, 4800, 5000, 5400, 5700, 8700
EN-EL2	1000mAh (Li-Ion)	Nikon: Coolpix 2500, 3500; SQ
EN-EL3	1400mAh (Li-Ion)	Nikon: D100, D70
EN-EL4 (Box)	2000mAh (Li-Ion)	Nikon: D2H, D2X
EN-EL5	1100mAh (Li-Ion)	Nikon: Coolpix 3700, 4200, 5200
EN-EL7	1000mAh (Li-Ion)	Nikon: Coolpix 8400, 8800.
EN4 (Box)	2100mAh (NiMH)	Nikon: D1X, D1H
BLM-1	1500mAh (Li-Ion)	Olympus: E-1, C-5060, C-8080; EVOLT E-300
Li-10B/12B	1070mAh (Li-Ion)	Olympus: C-50, C-60, C-70 Zoom, C-5000 Zoom, C-7000, C-770 Ultra Zoom, C-765 Ultra Zoom, C-760 Ultra Zoom; Stylus 300, 400, 410 D590
Li-30B	645mAh (Li-Ion)	Olympus: Stylus Verve (mju uMini Digital)
CGR-D07A	680 mAh (Li-Ion)	Panasonic Camcorder: PV-GS15, GS14, GS12, GS9, DV953, DV203, DV103, DV73, DV53, VM202, DV952, DV852, DV702, DV602, DV402, DV202, DV102, DV52, AG-DVX100A, AG-DVC30, AG-DVC7
CGR-D08A	800mAh (Li-Ion)	Panasonic Camcorder: PV-GS15, GS14, GS12, GS9, DV953, DV203, DV103, DV73, DV53, VM202, DV952, DV852, DV702, DV602, DV402, DV202, DV102, DV52, AG-DVX100A, AG-DVC30, AG-DVC7
CGR-D16A	1600mAh (Li-Ion)	Panasonic Camcorder: PV-GS15, GS14, GS12, GS9, DV953, DV203, DV103, DV73, DV53, VM202, DV952, DV852, DV702, DV602, DV402, DV202, DV102, DV52, AG-DVX100A, AG-DVC30, AG-DVC7
CGA-DU07A	680mAh (Li-Ion)	Panasonic Camcorder: Digital Camcorders: PV-GS200, GS120, GS55, GS70, GS50; DVD Camcorders: VDR-M70, M50, M30
CGA-DU14A	1360mAh (Li-Ion)	Panasonic Camcorder: Digital Camcorders: PV-GS200, GS120, GS55, GS70, GS50; DVD Camcorders: VDR-M70, M50, M30
CGA-S002	600mAh (Li-Ion)	Panasonic: Lumix DMC-FZ1, DMC-FZ10, DMC-FZ1k, DMC-FZ1S, DMC-FZ2, DMC-FZ3, DMC-FZ10K, DMC-FZ20, DMC-FZ15
CGA-S003	530mAh (Li-Ion)	Panasonic: D-SNAP SV-AV50A, SV-AS10, SV-AV50
CGA-S004	710mAh (Li-Ion)	Panasonic: DMC-FX7, DMC-FX2
SB-L110/LS110	1360mAh (Li-Ion)	Samsung Camcorder: SCD20, SCD21, SCD23, SCD24, SCD27, VP-D20, VP-D21, VP-D23, VP-D24, VP-D26, SCD31, SCD33, SCD34, VP-D30, VP-D31, VP-D33, VP-D34, VP-D39, SCD93, SCD99, VP-D93, VP-D97, VP-D99, SCD530, SCD590, VP-D530, VP-D590
SB-L110A	1900mAh (Li-Ion)	Samsung Camcorder: SCW97, VP-W90, VP-W97, SCW80, SCW87, VPW80, VPW87, SCL901, SCL903, SCL906, SCL907, VPL900, VPL906, VPL907, SCL810, SCL860, SCL870, VPL800, SPL850, SPL870
LIP-10/ B-9519	950mAh (Li-Ion)	Sony: DSC-F55K, DSC-F1
NP-F550	2000mAh (Li-Ion)	Sony: DKC-FP3, DSC-D700, Sony Mavica MVC-CD1000, MVC-FD-100 Sony Camcorder: BC-V500, CCD-SC55, CCD-SC65, CCD-TR3300, CCD-TR516, CCD-TR555, CCD-TR67, CCD-TR716, CCD-TR76, TR818, TR87, TR910, TR917, TR930, TR940, TRV101, TRV15, TRV215, TRV25, TRV36, TRV41, TRV43, TRV46, TRV51, TRV57, TRV58, TRV615, TRV62, TRV65, TRV66, TRV67, TRV68, TRV715, TRV72, TRV75, TRV81, TRV815, TRV82, TRV85, TRV87, TRV88, TRV93, TRV95, TRV98, TRV99; DCR-SC100, TR7000, TRV110, TRV120, TRV130, TRV210, TRV310, TRV315, TRV320, TRV510, TRV520, TRV525, TRV7, TRV720, TRC820, TRV9, TRV900, VX2000, VX2100; GV-D200, GV-D800, BC-V615, CCD-TR3000, TRV90, TRV91; DCR-TRV103, TRV5; DSC-D700.
NP-F750	3000mAh (Li-Ion)	Sony Camcorder: BC-V500, CCD-SC55, CCD-SC65, CCD-TR3300, CCD-TR516, CCD-TR555, CCD-TR67, CCD-TR716, CCD-TR76, TR818, TR87, TR910, TR917, TR930, TR940, TRV101, TRV15, TRV215, TRV25, TRV36, TRV41, TRV43, TRV46, TRV51, TRV57, TRV58, TRV615, TRV62, TRV65, TRV66, TRV67, TRV68, TRV715, TRV72, TRV75, TRV81, TRV815, TRV82, TRV85, TRV87, TRV88, TRV93, TRV95, TRV98, TRV99; DCR-SC100, TR7000, TRV110, TRV120, TRV130, TRV210, TRV310, TRV315, TRV320, TRV510, TRV520, TRV525, TRV7, TRV720, TRC820, TRV9, TRV900, VX2000, VX2100; GV-D200, GV-D800



# Rechargeable Batteries

For Digital Cameras and Camcorders

Li-Ion: Lithium Ion  
NiMH: Nickel Metal Hydride

Battery	Capacity	Fits These Cameras
NP-FM50	1400mAh (Li-Ion)	<b>Sony:</b> Cybershot DSC-F707, F717, F828, S30, S50, S70, S75, S85, Sony Mavica MVC-CD200, CD250, CD300, CD400 and CD500; <b>Sony Camcorder:</b> CCD-TRV108, TRV118, TRV128, TRV308, TRV318, TRV328, TRV608; DCR-DVD100, DVD101, DVD200, DVD201, DVD300, PC100, PC101, PC105, PC110, PC115, PC120BT, PC330, PC9, TRV10, TRV11, TRV140, TRV17, TRV18, TRV19, TRV20, TRV22, TRV230, TRV240, TRV25, TRV250, TRV260, TRV27, TRV30, TRV33, TRV330, TRV340, TRV350, TRV360, TRV38, TRV39, TRV460, TRV50, TRV530, TRV6, TRV70, TRV730, TRV740, TRV8, TRV80, TRV830, TRV840, TRV950
NP-QM71D	2760mAh (Li-Ion)	<b>Sony Camcorder:</b> CCD-TRV108, TRV118, TRV128, TRV308, TRV318, TRV328, TRV608; DCR-DVD100, DVD101, DVD200, DVD201, DVD300, PC100, PC101, PC105, PC110, PC115, PC120BT, PC330, PC9, TRV10, TRV11, TRV140, TRV17, TRV18, TRV19, TRV20, TRV22, TRV230, TRV240, TRV25, TRV250, TRV260, TRV27, TRV30, TRV33, TRV330, TRV340, TRV350, TRV360, TRV38, TRV39, TRV460, TRV50, TRV530, TRV6, TRV70, TRV730, TRV740, TRV8, TRV80, TRV830, TRV840, TRV950, HVL-IRM
NP-FP50	680mAh (Li-Ion)	<b>Sony Camcorder:</b> AC-VQP10, BC-TRP, DCR-HC20, DCR-HC30, DCR-HC40, DCR-HC65, DCR-HC85
NP-FP70	1360mAh (Li-Ion)	<b>Sony Camcorder:</b> AC-VQP10, BC-TRP, DCR-HC20, DCR-HC30, DCR-HC40, DCR-HC65, DCR-HC85
NP-FC11	780mAh (Li-Ion)	<b>Sony:</b> DSC-P2,P3,P5,P7,P8,P9,P10,V1,F77,FX77
NP-FT1	680mAh (Li-Ion)	<b>Sony:</b> DSC-T1, DSC-T11, DSC-L1
NP-FR1	1230mAh (Li-Ion)	<b>Sony:</b> DSC-F88, DSC-P100, DSC-P150, DSC-V3, DSC-T3, DSC-M1
RCR-V3	1200mAh (Li-Ion)	<b>Rechargeable version of the popular CR-V3 battery. Fits most cameras that take 2 AA batteries side by side.</b> <b>Casio:</b> QV-2900X, QV-4000, QV-3500EX, QV-2800UX, 3000EX <b>Konica/Minolta:</b> E203, E223, E323, F100, F200, F300, Revio KD-3300, 210z, 200z <b>Kodak:</b> CX7530, CX7430, CX7330, CX7310, CX7300, CX7220, CX6330, CX6230, CX6200, CX4310, CX4300, CX4230, CX4210, CX4200, DX6440, DX6340, DX4900, DX4530, DX4330, DX3900, DX3700, DX3600, DX3500, DX3215 <b>Kyocera:</b> Finecam L3v, L4v, L30 <b>Nikon:</b> 2100, 2200, 3100, 3200, 4100 <b>Olympus:</b> E-20N, E-100RS, E-10, D580, D575, D565, D560, D550, D540, D520, D510, D-490, D-460, D-40, D-395 (C160 in UK), D-390, D-380, D-370, D-230, D-150, D-100, C-750, C-740, C-730, C725 (EU), C-720, C-700, C-5050, C-4040, C-4000, C-3040, C-3030, C-3020, C-3000, C-211, C-2100, C-21, C-2040; Brio D100, Brio D150; C450 (EU), C360 (EU), C350 (EU), C310 (EU), C220 (EU), C160 (EU), C150 (EU) <b>Pentax:</b> Optio33LF, Optio33L, Optio33WR, Optio S30, Optio S40, Optio30, DigiBino 100, DigiBino 200, Optio 230, Optio 330GS, ist DS <b>Samsung:</b> V4, V5, V6, V40, V50, D30, <b>Sigma:</b> SD-9, SD-10 <b>Toshiba:</b> PDR-M700, PDR-T10 <b>Vivitar:</b> V3695, V3675, V3755, V3746, V3740, V3730, V3715, V3705, V3330, V3315,
RCR-V3 w/ Charger	1200mAh (Li-Ion)	Rechargeable version of the popular CR-V3 battery with charger.
RCR-V3 W/CHARGER & 2BAT	1200mAh (Li-Ion)	Rechargeable version of the popular CR-V3 battery. Includes two batteries and charger.
RCR123A W/CHARGER	Li-Ion	<b>Rechargeable lithium-ion version of the CR123A battery.</b> <b>Nikon:</b> N80, N75, N90, F75, F80, FM10, F100 MS-13 Battery Grip (x2), <b>Canon:</b> NP-300 Battery Pack (x2); EOS Elan 7/7E/7N, EOS 66, Sureshot A-1 <b>FujiFilm:</b> GX680III, S2 Pro <b>Minolta:</b> Dynax 7, Dynax 9 <b>Olympus:</b> IS-3 DLx <b>Pentax:</b> IQZoomEZY-S <b>Sigma:</b> SD9
AA Rechargeable 4 Pack	2300mAh (NiMH)	Rechargeable AA batteries in 4 pack.
90 Minute AA/AAA Quick Charger		Includes four 2300 mAh NiMH AA batteries and a DC car adapter for charging on the go.
AA Overnight Charger		Includes four 2300 mAh NiMH AA batteries.